Experiment 2

1. Ping

Of all the Windows 10 network commands, Ping is probably the one almost everyone knows about and has used before. The Ping command allows you to test the reachability of a device on a network. Pinging a host should return four data packets, if the data packets are not returned you know there is a problem with your network connection.

To run the basic command, at the prompt type:ping [host]

```
Microsoft Windows [Version 10.0.19042.928]
(c) Microsoft Corporation. All rights reserved.

C:\Users\Mark Kaelin Live>ping techrepublic.com

Pinging techrepublic.com [107.178.248.185] with 32 bytes of data:

Reply from 107.178.248.185: bytes=32 time=28ms TTL=115

Reply from 107.178.248.185: bytes=32 time=27ms TTL=115

Reply from 107.178.248.185: bytes=32 time=33ms TTL=115

Reply from 107.178.248.185: bytes=32 time=28ms TTL=115

Ping statistics for 107.178.248.185:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

Approximate round trip times in milli-seconds:

Minimum = 27ms, Maximum = 33ms, Average = 29ms

C:\Users\Mark Kaelin Live>
```

2. IPConfig

The IPConfig command is one of the more useful basic Windows network commands everyone should know and use to troubleshoot problems. The IPConfig command displays basic IP address configuration information for the Windows device you are working on. In fact, the command will display information for every network adapter that has ever been installed on your Windows 10 computer.

```
C:\Users\lab314->IPCONFIG

Windows IP Configuration

Ethernet adapter Ethernet:

Connection-specific DNS Suffix : mshome.net
Link-local IPv6 Address : fe80::2da1:44d:6f45:27bd%5
IPv4 Address : 175.175.1.139
Subnet Mask : 255.255.0.0
Default Gateway : 175.175.0.2

Ethernet adapter VirtualBox Host-Only Network:

Connection-specific DNS Suffix :
Link-local IPv6 Address : fe80::cd3d:f0b7:71a7:528%8
IPv4 Address : 192.168.56.1
Subnet Mask : 255.255.255.0
Default Gateway : : 255.255.255.0
```

To run the basic command, at the prompt type:**ipconfig**.

3. Getmac

Every network capable device on the internet has a unique identifying number called its MAC address. The number is assigned during manufacture and is established in the hardware of the device. Using the Getmac command, a user can determine the MAC address of their various network devices. Some administrators will use the unique MAC addresses of devices to limit

To run the basic command, at the prompt type:getmac

4. HostName

The Windows 10 HostName network command will simply display the current name of your Windows 10 computer. This is the name your computer uses to identify itself to the other devices and servers on your local network. You can find this name in the System information screen in the GUI, but this command is quicker.



To run the basic command, at the prompt type:hostname

5. NSLookUp

The NSLookUp Windows 10 network command displays information that you can use to diagnose Domain Name System (DNS) infrastructure. Using NSLookUp without a parameter will show the DNS server your PC is currently using to resolve domain names into IP addresses. I am using Google's DNS service because the server provided by my ISP is slow and prone to crashes.

```
C:\Users\Mark Kaelin Live>nslookup
Default Server: dns.google
Address: 2001:4860:4860::8888
>
```

To run the basic command, at the prompt type:nslookup

6. Tracert

Another handy tool for troubleshooting network connections in Windows 10 is the Tracert command. This command will trace the route a data packet takes before reaching its destination, displaying information on each hop along the route. Each hop of the route will display the latency between your device and that particular hop and the IP address of the hop, as shown in **below image**.

To run the basic command, at the prompt type:**tracert [host**] Where [host] is the name or IP address of a common host server (google.com, techrepublic.com, etc.).

7. Netstat

The Netstat command displays active TCP connections, ports on which the computer is listening, Ethernet statistics, the IP routing table, IPv4 statistics, and IPv6 statistics. When used without parameters, this command displays active TCP connections. The information this command provides can be useful in pinpointing problems in your network connections.

DEPARTMENT OF COMPUTER ENGINEERING (COMP)

(Accredited by NBA for 3 years, 4th Cycle Accreditation w.e.f. 1st July 2022)

Choice Based Credit Grading Scheme (CBCGS)

Under TCET Autonomy



Active Connections Foreign Address Proto Local Address State TCP 175.175.1.139:54216 175.175.5.218:ms-do ESTABLISHED TCP 175.175.1.139:54242 20.198.118.190:https **ESTABLISHED** TCP 175.175.1.139:54656 a23-212-254-41:https CLOSE_WAIT a23-212-254-41:https TCP 175.175.1.139:54657 CLOSE_WAIT a23-212-254-75:https CLOSE_WAIT TCP 175.175.1.139:54658 a23-212-254-8:https TCP 175.175.1.139:54659 CLOSE_WAIT TCP 175.175.1.139:54662 152.195.38.76:http CLOSE_WAIT TCP 175.175.1.139:54895 Lab220-10:ms-do **ESTABLISHED**

To run the basic command, at the prompt type:netstat

8. Arp

The Windows 10 network command Arp displays entries in the Address Resolution Protocol (ARP) cache, which contains one or more tables that are used to store IP addresses and their resolved Ethernet physical addresses. To get useful information from the Arp command you must provide a parameter. The most general parameter is /a, which displays current Arp cache tables for all interfaces.

```
C:\Users\lab314->ARP
Displays and modifies the IP-to-Physical address translation tables used by
address resolution protocol (ARP).
ARP -s inet_addr eth_addr [if_addr]
ARP -d inet_addr [if_addr]
ARP -a [inet_addr] [-N if_addr] [-v]
                Displays current ARP entries by interrogating the current
                protocol data. If inet addr is specified, the IP and Physical
                addresses for only the specified computer are displayed. If
                more than one network interface uses ARP, entries for each ARP
                table are displayed.
  -g
                Same as -a.
                Displays current ARP entries in verbose mode. All invalid
                entries and entries on the loop-back interface will be shown.
  inet addr
                Specifies an internet address.
  -N if addr
               Displays the ARP entries for the network interface specified
                by if addr.
  -d
                Deletes the host specified by inet_addr. inet_addr may be
                wildcarded with \ast to delete all hosts.
                Adds the host and associates the Internet address inet_addr
  - 5
                with the Physical address eth_addr. The Physical address is
                given as 6 hexadecimal bytes separated by hyphens. The entry
                is permanent.
                Specifies a physical address.
  eth addr
                If present, this specifies the Internet address of the
  if_addr
                interface whose address translation table should be modified.
```

To run the basic command, at the prompt type:arp /a

9. PathPing

Generally speaking, the Windows 10 network command PathPing combines the ping command with the tracert command, providing information about network latency and network loss at

intermediate hops between a source and destination.the PathPing command provides more detail than either ping or tracert can provide, such as latency reports and statistics on packet loss.

```
C:\Users\Mark Kaelin Live>pathping techrepublic.com
Tracing route to techrepublic.com [107.178.248.185]
over a maximum of 30 hops:
   MarkWKaelinm14x.cinci.rr.com [192.168.0.17]
 1 192.168.0.1
 2 142.254.147.225
    be60.lsvnkyfb02h.midwest.rr.com [74.128.6.173]
    be20.lsvmkyzo01r.midwest.rr.com [65.29.31.26]
 5 be24.clmkohpe01r.midwest.rr.com [65.189.140.162]
 6 107.14.17.252
    bu-ether11.chcgildt87w-bcr00.tbone.rr.com [66.109.6.20]
 8 72.14.222.220
Computing statistics for 200 seconds.
           Source to Here
                            This Node/Link
          Lost/Sent = Pct Lost/Sent = Pct
Hop RTT
                                             Address
                                             MarkWKaelinm14x.cinci.rr.com [192.168.0.17]
                               0/ 100 = 0%
                               0/ 100 = 0%
0/ 100 = 0%
 1
              0/ 100 = 0%
                                             192.168.0.1
 2
     11ms
              0/ 100 = 0%
                               0/ 100 = 0%
                                             142.254.147.225
                               0/ 100 = 0%
 3
     11ms
              2/ 100 = 2%
                               2/ 100 = 2%
                                             be60.lsvnkyfb02h.midwest.rr.com [74.128.6.173]
                               0/ 100 = 0%
              0/ 100 = 0%
                                             be20.lsvmkyzo01r.midwest.rr.com [65.29.31.26]
                               0/ 100 = 0%
                               0/ 100 = 0%
              0/ 100 = 0%
                                             be24.clmkohpe01r.midwest.rr.com [65.189.140.162]
 5
     24ms
                               0/ 100 = 0%
                               0/ 100 = 0%
              0/ 100 = 0%
                               0/ 100 =
                                         0%
                                             107.14.17.252
 6
                               1/ 100 = 1%
 7
              1/ 100 = 1%
                               0/ 100 =
                                         0%
                                             bu-ether11.chcgildt87w-bcr00.tbone.rr.com [66.109.6.20]
                               0/ 100 =
              1/ 100 = 1%
                               0/ 100 = 0% 72.14.222.220
Trace complete.
```

To run the basic command, at the prompt type:pathping [host]

Where [host] is the name or IP address of a common host server (google.com, techrepublic.com, etc.).

10. SystemInfo

The last command on our list is the SystemInfo command, which displays a detailed list of configuration information about your Windows 10 PC. The information listed by this command is too lengthy to mention in full but includes the installed version of Windows 10, the host name, the Product ID, the type and number of CPUs, RAM configuration, network card details and installed hotfixes.



DEPARTMENT OF COMPUTER ENGINEERING (COMP)

(Accredited by NBA for 3 years, 4th Cycle Accreditation w.e.f. 1st July 2022)

Choice Based Credit Grading Scheme (CBCGS)

Under TCET Autonomy



C:\Users\lab314->systeminfo

Host Name: LAB324-09

OS Name: Microsoft Windows 10 Pro OS Manufacturer:
OS Configuration:
OS Build Type:
Registered Owner:
Registered Operation OS Version: 10.0.19045 N/A Build 19045 Microsoft Corporation Standalone Workstation Multiprocessor Free

lab314-

Registered Organization:

Product ID:
Original Install Date: 01-11-2022, 09:10.0-3
0-01-2024, 14:25:22 Product ID: 00331-20140-75169-AA438 Original Install Date:

System Boot Time: 30-01-2024, 14:25.22

System Manufacturer: HP

System Model: HP 280 G4 MT Business PC

x64-based PC

1 Processor(s) Installed

1 Processor(s) Installed.

[01]: Intel64 Family 6 Model 158 Stepping 10 GenuineIntel ~3192 Mhz AMI F.20, 01-11-2018

BIOS Version:

Windows Directory: C:\Windows

System Directory: C:\Windows\system32

Result and Discussion:

Conclusion:

For Faculty Use

Correction	Formative	Timely	Attendance /	
Parameter	Assessmen	completion of	Learning	
S	t [40%]	Practical [Attitude [20%]	
		40%]		
Marks Obtained				